Digital2®

SMARTPHONE

Quick Start Guide

D554P

U.S Service Hotline : 1-888-863-0138
More support at www.d2pad.info

Overview

1. Volume Keys
2. Front Camera
3. Menu Key
4. Home Key
5. Back Key
6. Flash and Rear Camera
7. Power Button

Model: D554P

SIM Card Installation

A SIM card contains your phone number and other necessary data. Your device has dual SIM slots that both support 3G (WCDMA) SIM cards.

To Install the SIM Card

Make sure the device is turned off and the front facing down. Hold the device firmly and use the notch at the bottom corner to loosen the cover. Use material with a hard, thin edge such as your fingernail or a credit card to carefully run along the seam to loosen. Then lift the cover until it detaches completely.



2. Remove the battery first if it is in. Locate the SIM card slot and insert the SIM card with gold contacts facing down and cut-off corner facing out.

Note: The phone can support dual SIM cards. While both card slots support 3G SIM card (WCDMA), only one SIM card may connect to a 3G network at a time. If you need to use 3G operation, insert a 3G card into slot 1 (Default is SIM1 card. To enable/disable a 3G network go to **Settings > More... > Mobile networks > 3G service**). Some SIM cards may not have 3G function, nor be compatible with your device. Please consult your service provider for a replacement SIM card (fees may occur).

3. To turn on/off a SIM card go to **Settings > SIM management** and slide the SIM card sliders. To turn on/off a SIM card's data connection, go to **Settings > SIM management** and click on 'Data connection' option and select a SIM card that has 3G capability.



Charging Battery

New batteries are shipped partially charged. Before using your device, install and charge the battery. Batteries perform best after several full charge/discharge cycles.

Charging Your Battery

Please charge the battery using the following methods:

1. Charge the phone by connecting it to a computer via the USB cable.
2. Connect the USB cable to the phone and the AC adapter. Plug the AC adapter into an electrical outlet to start charging.

As the battery charges, an icon will appear in the status bar of the home screen. When the battery is fully charged, a full battery icon appears on screen.

Warning:

- Do not remove the battery while the device is charging.
- Use only the AC adapter & USB cable provided with your device.

Note: For safety, the battery will stop charging if in danger of overheating.

Audio/Sleep/Screen Lock

Audio Profile

From the home screen, touch 'App Menu' & select 'Settings'. Go to 'Audio profiles' and change the audio settings by clicking on the 'Settings' icon located next to the 'General' option. For your convenience, you may also select Silent, Meeting, or Outdoor preset options.

Sleep Mode

Turn on sleep mode to save your battery power.

1. On the home screen, touch 'App Menu' & select 'Settings'.
2. Select 'Display'.
3. Select 'Sleep' and choose a time interval from the list.

Automatic On/Off

1. On the home screen, touch the 'App Menu' & select 'Settings'.
2. Select 'Schedule power on & off'.
3. Set the time/days for your phone to turn on & off automatically.

Screen Lock

1. On the home screen, touch the 'App Menu' & select 'Settings'.
2. Select 'Security' then select 'Screen lock'.
3. Select the desired type of lock & follow the prompts to set up.

Phone Features

To Make Phone Calls

1. Touch the phone icon.
2. Select SIM1 card or SIM2 card.
3. Click on a contact from your contact list to make a call.



Dial
Click on the phone icon to bring up the phone dial.

Call Logs
Click on the time icon to see the most recent phone calls, received calls, and missed calls.

Contacts List
Select a contact then select the phone number to call. To end a call, touch the red 'END' button.

Groups
You may customize and group your contacts into different categories.

Favorite Contacts
You may create, customize, and save a list of your favorite contacts here.

Note: If you inserted two SIM cards, the dial screen is default for dual call. (Defined in the menu Settings > SIM management > Voice call)

Texting

Composing text messages

1. Touch the text icon on home screen.

2. Add recipients by typing a name, number, or email address in the 'To' field. Matching contact results will appear.

3. To add an attachment, touch 'Attach' & select from existing files or make a new attachment. To remove, select the attachment's 'Remove'.

4. Type your message.

5. Click the mail icon to send your text.


10:20 PM
New message
Yeah, texting you from my new phone.
How do you like it?
It's pretty nice.
Type text message
Q W E R T Y U I O P
A S D F G H J K L
Z X C V B N M
?123

Note: One text message has a limit of approximately 160 characters. If you continue to type after the limit is reached, your message will be delivered in multiples.

Connecting to E-Mails

Log into your e-mail accounts.

You may log-in to your e-mail accounts from the phone to access your e-mails.

From the Home screen select 'Email'.
Enter your email address, password and tap 'Next'.

Select which type of email account you are setting up and complete settings. (POP3 / IMAP / Microsoft Exchange Account)

You will need to enter your user name, password, and server information depending on the type of email account or your can change the settings by tapping 'Manual setup' at the top right corner screen. Tap 'Next' and select 'OK' to accept the activation notification.

Compose new:

1. Press MENU & select 'Compose'.

2. Add recipients by typing a name or email address in the 'To' field. Matching contacts will appear. Select a recipient or continue typing in the email address to send to multiple contacts.

3. Once finished typing the mail, select 'Send', 'Save as draft', or 'Discard'.

4. The reply tab contains 'Reply', 'Reply II' and 'Forward' options.

Delete message:

1. Go to Inbox to display messages.
2. Touch & hold the message you want to delete.
3. Select 'Delete'.

Notification

Accessing Notifications

Touch the status bar & slide your finger down the home screen, then press the upper right corner icon to open the notification list. Notification list reports the arrival of new messages, calendar events, & alarms etc.

Touch the icon to bring up 'Quick Function' menu that allows you to simply turn on/off certain functions by clicking on the function's icon.



Bluetooth Connection

Connecting to Bluetooth Devices

You can use the Bluetooth feature to send and receive calls using a headset or any other compatible accessories.

Turn on Bluetooth function.

1. Go to 'Settings'.
2. Slide the Bluetooth button from off to on.
3. Click on the word 'Bluetooth' to enter Bluetooth devices screen, which shows any 'paired' or 'connected' Bluetooth devices.
4. To search for new device to pair to, click on the 'search for devices' button.



Discoverability

By default, your phone is not "discoverable", which means other Bluetooth devices will not see your phone in their scans for Bluetooth devices. To make your phone discoverable, make sure you have turned Bluetooth on and touch the phone name to make it visible for 120 seconds.

Wi-Fi / Camera

Turn on Wi-Fi

On/off: Slide bar to turn on or off.
Settings: Touch the word 'Wi-Fi' to open the Wi-Fi settings screen. Select a network from the network list and provide a username and/or password if required.



Camera

Capture images or record videos and share with family and friends!



Wallpapers / Screen Captures

Changing Wallpapers

Press and hold on a blank spot on the home screen and the Home Screen option will pop up. Select 'Home Screen' and you may choose a wallpaper from your Gallery, Live Wallpaper, Video Wallpaper, and regular wallpaper.



Screen Capture

Pressing **Volume(-) and power button at the same time** to capture 'screenshot'. All captured screenshot will be saved under gallery.



File Transfer

Connecting Smartphone to PC

Connect the enclosed Micro USB to USB cable to your smartphone and computer.



Once connected successfully, on your phone, press '**Turn on USB storage**' button.



A new storage named **'D554P'** will appear on your 'My Computer'. Click in it to review files in the smartphone and/or to transfer documents between devices. When finished, press '**Turn off USB storage**' button on phone to disconnect.



Note: Photos taken with the camera will be saved under the 'DCIM' folder. Screenshots captured will be saved under 'Pictures' folder. Put Music files in the 'Music' folder for the files to be played properly.

Model: D554P

PRECAUTIONS

- Avoid drop or strong collision of the product or heavy vibration of the IPS screen, as it may cause damage or abnormal display of the IPS screen.
- Some storage capacity may not be available for data storage.This product cannot be used with any unauthorized chargers, otherwise it may burn the product, which is not covered by warranty.
- For any additional orginal charger, please contact customer service.
- To avoid any accidents, please do not use the product when driving or walking on the street.

Digital2® shall not be held liable for any loss of data caused by damage or repair of the product or any other reason. Please operate the product properly following the guidelines.

Note: *Pictures in this Quick Start Guide are for references only and may differ from actual product.*

©2014 All rights reserved. Digital2® and its Digital2® logo are registered trademarks of Digital2®. All other trademarks or registered trademarks are the property of their respective owners.